





















	Notes		Notes			Notes	
<b>CITROËN</b>											
Saxo 1.0-1.6 16V (99-03)	3-3,5	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80		FINAMATIC HP		↕			5
C1 1.0 (05->)	3,1	FIRST 500 5W-30, FIRST 400 5W-40	1,7	PONTONIC FDL 75W-90				↕			4
C2 1.1, 1.4, 1.6 16V (03->)	3,2	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			7
C3 1.1, 1.4, 1.6 16V, Pluriel, 2.0i 16V 100 kW(02->)	3-3,3	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			7
ZX 1.4 55 kW (91-98)	3,5	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			6,5
Xsara, Coupé, Picasso 1.6i 16V, 1.8i, 1.8i 16V (99->)	4,3-4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,8-2	PONTONIC BV 75W-80		FINAMATIC HP		↕			7-7,5
Xsara, Coupé, Picasso 2.0i 16V 122 kW (99->)	4,3-4,8	FIRST 400 5W-40	1,8-2	PONTONIC BV 75W-80		FINAMATIC HP		↕			7-7,5
Xsara, Coupé, Picasso 2.0i 16V 101 kW (99->)	4,3-4,8	FIRST 400 5W-40, FIRST 300 10W-40	1,8-2	PONTONIC BV 75W-80		FINAMATIC HP		↕			7-7,5
Xsara, Coupé, Picasso 2.0i 16V 100 kW (99->)	4,3-4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,8-2	PONTONIC BV 75W-80		FINAMATIC HP		↕			7-7,5
C4 1.4 16V, 1.6 16V (04->)	3,2-3,5	FIRST 500 5W-30, FIRST 400 5W-40	-	PONTONIC BV 75W-80				↕			6,5-7,5
C4 2.0i (04->)	4,3	FIRST 400 5W-40, FIRST 300 10W-40	-	PONTONIC BV 75W-80				↕			7,5-8
C4 2.0i 16V 125 kW (04->)	4,3	FIRST 400 5W-40	-	PONTONIC BV 75W-80				↕			7,5-8
C4 2.0i 100 kW (04->)	4,3	FIRST 500 5W-30, FIRST 400 5W-40	-	PONTONIC BV 75W-80				↕			7,5-8
Xantia V6 (97-2000)	5,5	FIRST 500 5W-30, FIRST 400 5W-40	1,9	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			10
C5 1.8 16V, 2.0 HPI, 2.0i 16V 100 kW, 3.0 V6 24V (01->)	4,3	FIRST 500 5W-30, FIRST 400 5W-40	1,8-1,9	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			8-9
C5 2.0i (01->)	4,3	FIRST 400 5W-40, FIRST 300 10W-40	1,8-1,9	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			8-9
C5 3.0 V6	5,3	FIRST 500 5W-30, FIRST 400 5W-40	1,8-1,9	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			12
C6 3.0i V6 158 kW (05->)	4,7-5,2	FIRST 500 5W-30, FIRST 400 5W-40	-	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			-
Evasion, Synergie 2.0 16V 100 kW (99-02)	4,2-4,9	FIRST 500 5W-30, FIRST 400 5W-40	1,8-2,2	PONTONIC BV 75W-80				↕			8,5-9
C8 2.0 16V (02->)	4,3	FIRST 500 5W-30, FIRST 400 5W-40	1,8-1,9	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			9
C8 2.2 16V (02->)	4,3	FIRST 500 5W-30, FIRST 300 10W-40	1,8-1,9	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			9
C8 3.0 V6 24V (02->)	5,3	FIRST 500 5W-30, FIRST 400 5W-40	1,8-1,9	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			12
Berlingo 1.1i, 1.4, 1.6 16V, 1.8i (99->)	3-5	FIRST 500 5W-30, FIRST 400 5W-40	1,8-2	PONTONIC BV 75W-80				↕			6,5-8
Berlingo 1.8i 66 kW (99->)	3-5	FIRST 500 5W-30, FIRST 300 10W-40	1,8-2	PONTONIC BV 75W-80				↕			6,5-8
Jumpy, Despatch 2.0 16V	4,3	FIRST 500 5W-30, FIRST 400 5W-40	1,9	PONTONIC BV 75W-80				↕			8
Jumper, Relay 2.0 4x4 (94-02)	5	FIRST 400 5W-40, FIRST 300 10W-40	1,8-2,8	PONTONIC BV 75W-80				↕	2,3	37	9,5
<b>Diesel</b>											
Saxo 1.5 D (99-03)	4,5	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			5
C1 1.4 HDi (05->)	3,8	FIRST 500 5W-30, FIRST 400 5W-40	1,9	PONTONIC FDL 75W-90				↕			4,4
C2 1.4 HDi 8V (03->)	3,8	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			5,7
C3 1.4 HDi 8V (01->)	3,8	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			5,7
C3 1.4 HDi 16V (01->)	3,8	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			5,7
C3 1.6 HDi, 1.6 HDi 16V DPF (05->)	3,8	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			5,7
Xsara, Picasso, 1.4 HDi (02->)	3,8	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			6,5
Xsara, Picasso 1.6 HDi (05->)	3,8	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			6,5
Xsara, Picasso, 1.9 D, 2.0 HDi (99->)	4-4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,8-2	PONTONIC BV 75W-80				↕			5,8-9
C4 1.6 HDi, 1.6 16V HDi DPF, 2.0 HDi DPF (04->)	4,5	FIRST 500 5W-30, FIRST 400 5W-40	-	PONTONIC N 80W-85				↕			8-8,5
Xantia 1.9 TD, 2.0 HDi (99-01)	4,3-4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80		FINAMATIC HP		↕			7-8
C5 1.6 HDiF DPF (05->)	4,5	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			8,5
C5 2.0 HDi (66 kW) DPF (01->)	4,5	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			8,5
C5 2.0 HDi (81 kW) DPF, 2.0 HDi 16V (100-136) DPF	4,5	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			8,5
C5 2.0 HDiF (05->)	4,5	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			8,5
C5 2.2 HDi DPF (01->)	4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80		 (ATF, LT 71141)		↕			11
C6 2.7 V6 HDiF	5,5-5,8	FIRST 500 5W-30, FIRST 400 5W-40	-			 (ATF, LT 71141)		↕			-
C6 2.7 V6 HDi V6 153 kW DPF (05->)	5,5-5,8	FIRST 500 5W-30, FIRST 400 5W-40	-			 (ATF, LT 71141)		↕			-
Evasion, Synergie 1.9 TD, 2.0 HDi 16V (99->)	4,3-4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80				↕			7-9
C8 2.0, 16V DPF, 2.2 HDi 16V DPF (02->)	4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80				↕			8
Berlingo 1.9 D 71 51 kW, 2.0 HDi 66 kW (99->)	4,3	FIRST 500 5W-30, FIRST 400 5W-40	2	PONTONIC BV 75W-80				↕			8
Jumpy, Despatch 1.9 D, 2.0 HDi, 2.0 HDi 16V	4-5	FIRST 500 5W-30, FIRST 400 5W-40	1,8	PONTONIC BV 75W-80				↕			9
Jumper, Relay 2.0 HDi, 2.2 HDi (02->)	5,3-8	FIRST 500 5W-30, FIRST 400 5W-40	1,85-2,8	PONTONIC BV 75W-80	14	 (ATF, LT 71141)		↕		33	10-13,5
Jumper, Relay 2.8 HDi (02->)	5,3-8	FIRST 500 5W-30, FIRST 400 5W-40	1,85-2,8	PONTONIC BV 75W-80	14	 (ATF, LT 71141)		↕		33	10-13,5