













































	Notes		Notes			
<b>HONDA</b>										
Logo	3,6	FIRST 500 5W-30, FIRST 400 5W-40	1,8	 (MTF 94 gear oil)		FINAMATIC HP				4,7
Jazz 1.2, 1.4i-DSI	3,6	FIRST 600 0W-30, FIRST 500 5W-30	1,5	 (MTF 94 gear oil)		 (Honda ATF Z1)				5-5,5
Civic 1.3i, 1.5i, 1.6i (sohc/dohc) (92-01)	3,3-4	FIRST 500 5W-30, FIRST 400 5W-40	2,3	FIRST 300 10W-40	44	FINAMATIC HP				4,5-6
Civic, Coupé 1.4i, 1.5i, 1.6i, VTi (94-01)	3,5	FIRST 500 5W-30, FIRST 400 5W-40	1,8	FIRST 300 10W-40	44	FINAMATIC HP				4,5-5
Civic 1.4, 1.6, 1.7, Type R 2.0 (01->)	3,2-4,5	FIRST 600 0W-30, FIRST 500 5W-30	1,5	 (MTF 94 gear oil)		 (Honda ATF)				4-5,3
FR-V 1.7, 2.0	3,5-4,2	FIRST 600 0W-30, FIRST 500 5W-30	1,5-1,8	 (Honda MTF II)						4,4-5
CRX 1.6i (sohc/dohc) (92-01)	3,3-4	FIRST 500 5W-30, FIRST 400 5W-40	2,3	FIRST 300 10W-40	44	FINAMATIC HP				4,5-6
Concerto 1.4i, 1.5i, 1.6i, 1.6i-16	3,5-3,8	FIRST 500 5W-30, FIRST 300 10W-40	1,8	FIRST 300 10W-40	44	FINAMATIC HP				5,5
Accord, Aerodeck 1.6-2.3i, Type R (93-02)	3,3-4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,9-2,4	FIRST 300 10W-40	44	FINAMATIC HP				4,5-7,5
Accord Coupé 2.0i, 2.2i (92-02)	3,5-4	FIRST 500 5W-30, FIRST 400 5W-40	1,9-2,4	FIRST 300 10W-40	44	FINAMATIC HP				6,5-7,5
Accord 2.0 16V, 2.4 16V (03->)	4,2	FIRST 600 0W-30, FIRST 400 5W-40	1,9	 (Honda MTF II)		 (Honda ATF Z1)				4,5-5,4
Prelude 2.0i, 2.2i, VTEC, 2.3i (92->)	3,5-4,8	FIRST 500 5W-30, FIRST 400 5W-40	1,9	FIRST 300 10W-40	44	FINAMATIC HP				6-8
Legend, Coupé V6 3.2i-24, 3.5-24V (91->)	4,7	FIRST 500 5W-30, FIRST 400 5W-40	2,3	FIRST 300 10W-40	44	FINAMATIC HP		1,1	PONTONIC MP 80W-90	7,5
S2000	4,8	FIRST 400 5W-40	1,5	 (MTF 94 gear oil)				0,8	PONTONIC MP 80W-90	7,5
NSX 3.0, 3.2 V6-24	5	 (API SG 10W-30)	2,7	FIRST 300 10W-40	44	FINAMATIC HP				12
CRV 2.0i 16V, 4x4 (->02)	3,8	FIRST 500 5W-30, FIRST 400 5W-40	1,7-2,2	 (MTF 94 gear oil)		FINAMATIC HP		1-1,2	FINAMATIC HP	6
CRV 2.0i 16V, 4x4 (02->)	4,2	FIRST 600 0W-30, FIRST 500 5W-30	1,9	 (MTF 94 gear oil)		 (Honda ATF Z1)		1	 (Honda DPSF -)	33
HR-V 1.6	3,3	FIRST 500 5W-30, FIRST 400 5W-40	1,7-1,8	 (MTF 94 gear oil)		FINAMATIC HP		1-1,2	 (Honda ATF -)	3-4
Stream 1.7, 2.0	3,2-4,2	FIRST 600 0W-30, FIRST 500 5W-30	1,5-1,8	 (MTF 94 gear oil)		 (Honda ATF)				4-6
Shuttle 2.2 16V	4,9	FIRST 500 5W-30, FIRST 400 5W-40				FINAMATIC HP				30
<b>Diesel</b>										
Civic 2.0 TDi	4,5	FIRST 400 5W-40	2,2	 (MTF 94 gear oil)						8,5
Civic 1.7 CTDi	5	FIRST 500 5W-30	2	 (MTF 94 gear oil)						5,3
Accord 2.0 TDi	4,5-5,5	FIRST 400 5W-40	1,9-2,2	 (MTF 94 gear oil)						7
Accord 2.2 CTDi	5,9	FIRST 500 5W-30	-	 (Honda MTF II)						6,8
CRV 2.2 CTDi	5,9	FIRST 500 5W-30	1,9	 (MTF 94 gear oil)				1	 (Honda DPSF -)	33